

TIE DYE CHEMISTRY

LAB MSC 1

From Flinn CHEM FAX Publication #10075

INTRODUCTION

The art of dyeing clothing fibers probably originated in India or China no later than 2500 BC. Most natural dyes came from parts of plants; such as the bark, berries, flowers, leaves, and roots. Because these dyes did not have a strong attraction for the fibers being dyed, a process known as *mordanting* was used to improve colorfastness. To react with acidic dyes, fibers were treated with basic or metallic mordants that might include solutions of aluminum, copper, iron, or chromium salts. Compounds formed by the dye and the mordant, called *lakes*, prevented the colors from washing out and made the color longer lasting. Such natural dyes became less and less important as synthetic dyes that produced brighter colors were developed. Today, logwood black is the only natural dye widely used.

In 1856, William Henry Perkin began the synthetic organic chemical industry by accidentally discovering the purple dye, mauveine, when he tried to produce quinine from aniline. The synthetic dyes were known as coal tar dyes because the six-membered ring structures of carbon atoms were all derived from coal tar. Congo Red was the first dye discovered with so great an affinity for cellulose that a mordant was not required.

About 100 years after Perkin's first discovery, fiber-reactive dyes capable of forming covalent linkages with the fiber were discovered. Fiber-reactive dyes are wash-fast. During dyeing, dye molecules must diffuse from the aqueous solution into the fibers. Fibers such as cotton absorb water readily and are said to be hydrophilic, while fibers such as polyester absorb water with difficulty and are described as hydrophobic. Dyeability is influenced if a fiber can somehow carry an ionic charge and better interact with the oppositely charged colored ions. To dye cellulose, a reactive dye must combine with the hydroxyl groups in the fiber.

Tie dyeing is one of the oldest methods of printing designs on fabrics. Typically, parts of the fabric are bunched together in a design and knotted or tied together with string. Tied sections are protected from absorbing the dye and patterns are created.

PURPOSE

The purpose of this activity is to use the process of tie dying to illustrate a variety of chemical concepts, including equilibrium, kinetics, and pH.

MATERIALS

100% cotton T-shirts, prepared for dyeing	Plastic drop cloth
Plastic bucket	1000 mL beakers
Zipper-sealed bags or small trash bags	Disposable plastic gloves
Rubber bands, size 33 (3½"L x ⅛"W)	Reactive dye solutions
Beral-type pipets, 15 mL bulb capacity	Newspaper
2 L sodium carbonate activator solution	

SAFETY

- Always wear safety glasses in the lab.
- Wear disposable plastic gloves and chemical-resistant aprons. Old clothes and shoes should also be worn because once the reactive dye makes contact with clothes, it will **not** wash out.
- Use filled pipets appropriately. Don't get sloppy or squirt others with the dye solutions.
- Use caution handling the sodium carbonate solution, it is very basic. Wear plastic gloves when placing the T-shirt in the solution and when the shirt is wrung out at the end of the activation period.

DISPOSAL: Check with you teacher for disposal instructions.

PROCEDURE

1. Wear gloves throughout the procedure.
2. Fill the plastic bucket with 2 liters of sodium carbonate activator solution.
3. Soak the T-shirts in the sodium carbonate activator solution for a minimum of 20 minutes. (Soaking for 2 hours maximizes the number of possible bonding sites.)
The ionization of cellulose increases with the increasing alkalinity of the solution and above pH 8 there is an adequate number of ionized hydroxyl groups in the fiber for most dyeing purposes.

4. After the T-shirt has soaked, wring the T-shirt out over the plastic bucket. Add more sodium carbonate solution to the bucket as needed. **CAUTION:** The sodium carbonate activator solution is very basic, so be sure to wear gloves when placing the shirts in the solution and when wringing out the shirts at the end of the activation period.
5. Shirts are now ready to fold. Please refer to **Tie-Dyeing Instructions**, pages 4 and 5, for directions for creating various designs.
HINT: Folding should be done in an area separate from the dyeing area to prevent shirts from picking up dye by mistake.
6. Dyeing can be done on oven racks placed over sinks or on racks placed over enough newspaper to absorb excess dye.
7. After a shirt is placed on a clean rack, dyes can be applied using jumbo beral-type pipets. Apply the dye to one side of the shirt by slowly squirting the reactive dye solution onto each section of the shirt. Once you are done dyeing one side of the shirt, turn the shirt over and repeat the dyeing process. Allow shirts to drain for 15 minutes.
8. Place the shirt in a zipper-sealed bag or small trash bag and close it to keep the shirt moist. **Be patient.** Keep the shirt in the bag for 24 hours to allow the dyes to react completely.
9. At home, rinse the shirt in warm water (75-90°F) in order to remove the unreacted dye and the sodium carbonate activator. Change the water and continue to rinse. Repeat until the water remains clear and the shirt does not feel slippery.
10. Wash as many as 10 shirts at a time in a hot water cycle with 2 tablespoons of a pre-wash such as Joy® or Dawn® dish soap. Dry the shirts on the hottest dryer setting. The shirts are now safe to wash with other clothing using normal detergents. The reactive center on the dyes is a dichlorotriazinyl group, so do not use bleaches on the shirts.
11. Now be creative! Dye other types of clothing and try other patterns for folding. You can even use this lab as a fundraiser for the science club at your school.

Tie-Dying Instructions

Spirals

Lay your material on a flat surface. Place your thumb and a couple of fingers together on the cloth at the point, which will be the center of the design. Using the weight of your fingers to hold the cloth in place start twisting. After each twist flatten the material with the palm of your hand to keep the folds from rising. With your other hand, bring the loose ends into the circle and continue twisting until the whole thing looks like a fat pancake.



Now take rubber bands, and without disturbing the shape of the pancake slide the bands under the cloth so that they criss cross at the center, using as many as necessary to retain the shape. You can also use the rubber bands to divide up the area to sections that you want the colors to go.



Pleats

Lay cloth on flat surface. Place thumbs of both hands firmly on the cloth. Position fingers about an inch or two in front of your thumbs, in pinch the fabric to raise a fold. Continue to pinch up more pleats until you reach the end of the cloth. You can change directions as much as you want by gathering more material in one hand than the other.

Be careful not to lose any pleats. Loop rubber bands very tightly around all of the pleats several times. You can use as many as you want. This technique is also employed in tying ovals, squares, diamonds, or any shape you can imagine with has symmetry.



Stripes

Roll the cloth very loosely forming a long tube the stripes will be at right angles to the tube.



Tie at one-inch intervals or as far apart as you want the stripes to run. Loop rubber bands around the tube a few times make sure they are very tight.




Patterns

Fold the cloth along an imaginary line, which will run through the intended form.



Draw half of the intended design with a pencil starting and ending on the crease.



Form pleats starting at one end of your line. Try to keep that line in the center between your hands while pleating until you come to the end of your line.



Wrap rubber bands around all the gathered pleats several times. Now you can continue wrapping to the up and back or tie an electric ball or anything else you can think of.



Circles

The circle design is relatively simple to create, yet it is easily one of the most dramatic. Just pick up the cloth with thumb and forefinger at the point you choose to be the center of the circle.



With your other hand, try to arrange fairly neat and evenly spaced pleats around the central axis like a closed umbrella. Smooth the cloth down, and hold rightly at the base. Now let go of the top.



With string or rubber bands, tie a strong -knot around the base. Continue wrapping to the tip and back again and secure at the base. Make sure the ties are very tight.



ANSWER SHEET

Name _____

Name _____

Period _____ Class _____

Date _____

TIE DYE CHEMISRTY

1. If you dyed a rainbow spiral on a shirt and then soaked it in a black dye bath, the result would be a black shirt with a rainbow spiral pattern. Why doesn't the entire shirt dye black?

2. Why do you have to pre-wash the items being dyed?

3. Why is 100% cotton the best type of cloth to use with fiber reactive dyes?

4. What are some advantages of fiber reactive dyes?

5. What is the purpose of soaking the shirts in sodium carbonate?